

**Jamson Labs**

Quality Chemicals Since 1973

Directions:**Dish Washing Machines -**

Fill tank with water, add one ounce per gallon. Let machine run for 30 minutes. Drain tank. Refill with water and drain to rinse.

Pressure Washing Machines -

Fill holding tank with product, run machine with wand placed in tank. Allow to circulate for 10 -15 minutes. Run tank empty when clean.

Excellent for descaling air conditioners, dish washers, heat exchangers, boilers, coolers, etc.

DANGER:

DO NOT MIX WITH OTHER CHEMICALS - MIXING WITH BLEACH WILL RELEASE DANGEROUS CHLORINE GAS.

DO NOT TAKE INTERNALLY. HARMFUL IF SWALLOWED.

DO NOT BREATHE VAPOR OR FUMES

AVOID CONTACT WITH EYES AND SKIN AND CLOTHING.

CAUTION: KEEP OUT OF REACH OF CHILDREN.

Scale Away

CONCENTRATED LIME REMOVER

INDUSTRIAL STRENGTH
REMOVES:

**SCALE, RUST, MINERAL DEPOSITS
AND LIME FROM DISH WASHING AND
PRESSURE WASHING MACHINES.**

 1 Gal. 5 Gal. 55 Gal. 275 Gal.**TRANSPORT INFORMATION:**

Proper Shipping Name -
Corrosive liquids, N.O.S.,
(Contains Hydrochloric Acid)
DOT Hazard Class - 8 Packing Group - III
ID# - UN 1760

Inhalation: Remove affected person to fresh air. If breathing difficulty persists, seek medical attention.

Skin: Remove contaminated clothing; wash affected area with soap and water; if irritation persists, seek medical attention. Launder contaminated clothing before reuse.

Eyes: Check for and remove any contact lenses. Immediately flush eyes with clear running water for 15 minutes while holding eyelids open. Seek medical attention immediately.

Ingestion: Drink two glasses of water followed by milk, milk of magnesia or other non-alcoholic liquids; DO NOT induce vomiting; seek medical attention immediately.

**Jamson Labs**

Quality Chemicals Since 1973

Jamson Laboratories Inc.

(813) 855-4565

FAX (813) 854-3133

In Case Of Chemical Emergency Contact
Chem-Tel 24 Hours (800) 255-3924