

PowerKleen
Quality Chemicals • Superior Service

Shine On is an alkaline liquid designed for use as a pre-soak for silverware and silver table service. It also removes tarnish and stains from silver plate and sterling utensils. When used as directed, will not harm fine silver. As an excellent pre-soak, it quickly penetrates and saturates soils for their more efficient removal in dishwashing machines. Produces excellent cleaning results in both hard and soft water supplies. This detarnishing procedure removes sulphur type tarnish and stains with an easy application in a soak solution utilizing aluminum foil. A high quality product, provides economical, time-saving and problem solving results.

Directions:

Pre-soak: To soften soil material on silverware, (including cream rings in silver creamers), pre-soak all silver in one (1) or two (2) ounces per gallon solution of PRE-SOAK prior to machine washing.

DETARNISHING: For the removal of sulfur type tarnish and stain dilute one ounce per gallon of water at 140°F, minimum. Silver must be in contact with aluminum to facilitate the galvanic action necessary to detarnish. **Aluminum foil may be placed in the bottom of a plastic container.**

DANGER:

DO NOT TAKE INTERNALLY. HARMFUL IF SWALLOWED.

AVOID CONTACT WITH EYES AND SKIN

CAUTION: KEEP OUT OF REACH OF CHILDREN.

Shine On

FLATWARE/TABLEWARE CLEANER & DETARNISHER

FAST-ACTING PROFESSIONAL-GRADE FORMULATION

- EFFECTIVE PRE-SOAK FOR FLATWARE AND TABLEWARE
 - EXCELLENT CLEANING AGENT
 - SAVES TIME AND HARD WORK
- SOFTENS SOILS – INCLUDING CREAM RINGS

1 Gal. 5 Gal. 55 Gal. 275 Gal.



TRANSPORT INFORMATION:

Proper Shipping Name -
Corrosive Liquids, N.O.S.,
(Contains Sodium Metasilicate)
DOT Hazard Class - 8 Packing Group - II
ID# - UN 1760

Inhalation: Remove affected person to fresh air; wash mouth and nasal passages with water repeatedly; if breathing difficulties persist seek medical attention.

Skin: Remove contaminated clothing; wash affected area with soap and water; DO NOT attempt to neutralize with chemical agents; if irritation persists, seek medical attention. Launder contaminated clothing before reuse.

Eyes: Check for and remove any contact lenses. Immediately flush eyes with clear running water for 15 minutes while holding eyelids open. Seek medical attention immediately.

Ingestion: Drink two glasses of water or milk; give diluted vinegar or lemon juice to conscious person; DO NOT induce vomiting; seek medical attention immediately.

PowerKleen
Quality Chemicals • Superior Service

Power Kleen Corporation
To Reorder, Call: (813) 854-2648
FAX (813) 854-3133

In Case Of Chemical Emergency Contact
Chem-Tel 24 Hours (800) 255-3924
www.PowerKleen.com